



📍 1001 Corporate Ln. Export, PA 15632
☎ 412-856-9200
🌐 www.CSEcorporation.com

Technical Bulletin #TB115
BioPak 240R PRO PP Facemask Adapter Interface

Product Focus:

Part Number	Part Description
B6025003091	PRO Mask-Small , EN
B6025003211	PRO Mask-Small-Drink, EN
B6025003090	PRO Mask-Medium , EN
B6025004020	PRO Mask-SM, NIOSH
B6025004021	PRO Mask,SM,Drink,NIOSH
B6025004030	PRO Mask,Med,NIOSH
B6025004031	PRO Mask,Med,Drink,NIOSH

The CSE Biomarine Product Team has received two confirmed reports of the PRO PP Facemask Adapter dislodging from the facemask during training exercises.

Take the proper steps to be sure you are protected in any emergency or training scenario:

- Complete a thorough inspection of your PRO PP Facemask prior to use.
- Follow donning instructions on Page 18 of your BioPak 240R User Instructions with emphasis on the instructions section 4.3.4 (see below).
 - “Depress the push button of the facemask front port and insert the breathing hose adapter into the port. Release the push button and tug the breathing hose adapter to ensure that it securely anchored.”



- Remember, you can find the latest version of the User Instruction (47C9090 Rev. F) [here](http://www.csecorporation.com/resources), or by going to <https://www.csecorporation.com/resources>



 **1001 Corporate Ln. Export, PA 15632**
 **412-856-9200**
 **www.CSEcorporation.com**

Please note: This part cannot be repaired in the field. If any issue is found, the facemask should be removed from service. Contact CSE to arrange for evaluation of your facemask. Do not try to service your facemask in the field.

If you have received this technical bulletin but are not responsible for maintaining or wearing the BioPak 240R, please send this information to the proper individual(s).

Our Commitment:

CSE Corporation holds itself to the highest standards of safety, production excellence, and quality assurance because your trust and safety are paramount. *We're in this for life.* While these field reports include only 0.3% of product in the field, we are proactively evaluating findings and providing this information to you to demonstrate CSE Corporation's commitment to your safety.

We will continue to keep you informed if added information and guidance is necessary.

CSE Corporation
1001 Corporate Lane
Export, PA 15632
Phone: 412-856-9200
Email: customerservice@csecorporation.com
Web address: csecorporation.com