

This presentation should not be considered a final statement of NIOSH policy or of any agency or individual who was involved. This information is intended for use in advancing knowledge needed to protect workers. Comments regarding this presentation may be submitted to the [NIOSH Docket Office](#).



Cyrano Sciences

Array Based Chemiresistor Sensors for Residual Life and End of Service Life Indication

October 17, 2002


Product Platforms

Cyranose™ 320




*Handheld Point
Detector / Identifier*

NoseChip™




Front



Back

- 4 to 16 Sensors
- < 1 cm; Low Power
- Wireless Comm. to 300 ft
- Disposable
- Integrated Systems

Sensigent™





Intelligent Sensor Networks

- Data Fusion

Cyrano Sensor Technology

Polymer Composite Sensor Array


Sensor Construction




**Conductive
Polymer
Composite**

Cyrano Sensor Technology


Array Based Chemical Sensing



Vapors pass over the polymer composite sensors; swelling produces a change in resistance




Resistance change is measured for each of the 32 sensors




Using pattern matching algorithms, the data is converted into a unique response pattern

Cyrano Sensor Technology

A resistive measurement is taken for each of the 32 sensors:




The vapor passes over the polymer matrix and the swelling produces a change in resistance



A relative resistance measurement is made for each of the 32 sensors

RLI Prototype Development



Cyrano RLI sensors

- disposable inside filter cartridge
- intrinsically safety
- sensor spot < 1 mm



Alarm !

RLI %, unit ID, date & time

Cyrano RLI annunciator


- durable inside mask
- wireless TX/RX

power: micro Watts

battery: weeks to > 1 year



Cyrano NoseChip™



Applications:

Individual Protection

- Filter RLI / ESLI - NIOSH
- Personal badges - CBIRF

Collective Protection

- Filter Monitoring in field shelters and buildings

Distributed Wireless Monitoring

- Permanent Installations (buildings)
- Temporary Networks (events)

Features:

- Sensor array; tunable
- Low cost & Low power
- Wireless communication
- < 3 cm
- Capable of integration

Filter Breakthrough Testing


- **Naval Research Laboratory –**
Comparison of sensor technologies for individual and collective protection
- **NIOSH –**
Contract awarded to Cyrano Sciences for prototype RLI for personal protective equipment
- **NASA –**
Detection of filter breakthrough detection in animal housing experiments

Filter Breakthrough Testing


Naval Research Laboratory

- Comparison of Cyrano chemiresistor, SAW, PID and colormetric sensors
- Challenge Vapor: DMMP
- Cyrano's sensors perform as well as SAW sensors
 - Fast, sensitive response
- Internal testing shows Cyrano sensors use 300% less power than SAW sensors

NRL Filter Breakthrough Tests*




Frequency (SAW) and resistance (Chemiresistor) change upon DMMP breakthrough.
DMMP concentration = 1500 mg/m³. Flow rate = 10 lpm. T = 21°C, %RH = 25%.
Sensors position = middle of 5 cm bed (2.5 cm from the bottom), flush mounted.
Breakthrough time = 10000 sec.



Cyrano chemiresistor sensors are as sensitive and respond as rapid as SAW sensors

NRL Filter Breakthrough Tests*

DMMP run 1-31-00 : CR 2 Data



Date: 01/31/2000
Length of Trial: 9.00 hr
Sample Rate: 10/min
DMMP: 1500 mg/m³ (300 ppm)
Flow rate = 10 Lpm. T = 30°C
%RH = House Air
Sensor position:
middle of 2.5 cm bed
Breakthrough time @ 4000 sec.

Data from NRL
R. Andrew McGill


*Cyrano chemiresistor technology successfully used
as Filter Breakthrough/Residual Life Indicator*

RLI for Air Purifying Respirators

- Contract awarded for further development of Residual Life Indicator (RLI) technology.
- 3 part program includes:
 - Determination of detection limits and sensor selection
 - Filter breakthrough detection
 - Development of prototype mask/detector system
- One year program; prototype detector systems delivered June 2003



Determination of Detection Limits

- Determine detection limit of 10 VOC's chosen by NIOSH using system illustrated below
- Select sensors for breakthrough testing by “ranking” them according to detection limit to different chemical families




MDL Studies for TICs, CWA

Ammonia	SNR > 100	at REL 25 ppm
Nitrogen Dioxide	SNR > 400	at REL 3 ppm
Phosgene	SNR > 10	at REL 2 ppm





NIOSH Filter Breakthrough Test Bed



A schematic representation of the RLI test fixture

NIOSH Filter Breakthrough Test Bed



NIOSH *Vapor Generation System*




Capabilities

- Concentration:
 <1 ppm to Saturation
- Flow Rate:
 0.1 to 100 Lpm
- Solvents, TICs,
 CWA simulants
- Mixtures

Multi-Filter Breakthrough (“RLI”)


Single 4hr test: 10/15/02

Normalized Resistance Change



Challenge concentration 6000ppm


NIOSH Filter Breakthrough Test Bed



A schematic representation of the RLI test fixture


Breakthrough Event Detection

Normalized Resistance Change



Time

Breakthrough Event Detection



NIOSH Recommended Filter Challenge Vapors

Challenge Chemical	Test Conc. (ppm)	Breakthrough Conc. (ppm)	IDLH (ppm)	REL / TLV 8-hr TWA (ppm)	<i>RLI Detector Req.</i>
	<i>draft</i>	<i>draft</i>			
Cyclohexane	3900	10	1300	300	?
Ammonia	2500	12.5	300	25	?
Formaldehyde	500	1	20	< 1	?
Phosgene	250	1.25	2	0.1	?
Phosphine	300	0.3	50	0.3	?
Cyanogen Chloride	300	2	n.a.	0.3	?
Hydrogen Cyanide	1000	4.7	50	4.7	?
Hydrogen Sulfide	940	5	100	10	?
Sulfur Dioxide	1500	5	100	2	?
Nitrogen Dioxide	200	1	20	3	?