

Standards Development Efforts for Full Facepiece Air-Purifying Respirators (APR) Used to Protect Emergency Response Workers Against Chemical, Biological, Radiological and Nuclear (CBRN) Agents and Air-Purifying Escape Respirators to protect workers against CBRN Agents

Hilton Garden Inn, Canonsburg, PA
October 16 – 17, 2002







Agenda – October 17

<u>Time</u>	<u>Topic</u>	<u>Presenter</u>
8:30 - 8:40	Air Purifying Respirator Overview	Mr. Jonathan Szalajda, NIOSH
8:40 - 9:30 9:30 - 10:00	APR CBRN Standard Implementation Open Comment Period – CBRN APR	Mr. Les Boord, NIOSH
10:00 - 10:30	Break (including Sub Panel discussion Environmental Conditioning and Human Factors Testing	ns) Mr. Frank Palya, NIOSH
	SMARTMAN and Chemical Warfare Agent Testing	Mr. Terrence Cloonan, NIOSH Mr. Raymond Lins, SBCCOM
10:30 - 11:00	Simulant Project	Mr. Frank Palya, NIOSH
11:00 - 11:45	Attendee Presentations	Mr. William Haskell SBCCOM
		Mr. G. Berndtsson, SEA
		Mr. T. Burch, Cyrano Sci.
11:45 - 1:00	Lunch	





4

Agenda – October 17

1:00 - 1:30	Sub Panel Discussions * Environmental Conditioning * SMARTMAN and CWA Testing	Mr. Frank Palya, NIOSH Mr. Ray Lins, SBCCOM Mr. Terrence Cloonan, NIOSH
1:30 – 2:15	Air-Purifying Escape Respirator Concepts	Panel
2:15 – 3:15	Open Comment Period – CBRN Es	scape Respirators
3:15 - 3:30	Break (including Sub Panel Discussions)	
3:30 – 3:45	Standards Development Schedule	Mr. Les Boord, NIOSH
3:45 – 4:45	Open Comment Period	
4:45 – 5:00	Summary and Conclusions	







CBRN APR Respirator Concepts- Overview

Three Tiers of Requirements:

- 42 CFR, Part 84 Applicable Sections
- Requirements Derived from other Standards/Specifications
- Special CBRN APR Requirements







CBRN APR Respirator Concepts-Overview

- Special CBRN APR Requirements
 - Systems CWA Penetration / Permeation
 - Laboratory Respiratory Protection Level
 - Gas Life Testing







CBRN APR – Test Procedure Validation

- NIOSH is developing Standard Test Procedures for the special CBRN APR Requirements
- Verification Testing is ongoing
- Sub Panel Breakout Sessions to discuss testing







CBRN APR Standard Implementation

- Implementation
- Manufacturing Prototype Testing Program
- Use Scenarios
- Quality Assurance
- Cost







Implementation

- Comments on Concept
 - Open until November 15, 2002
- CBRN APR Draft Standard Published in Federal Register
 - December 2002
 - 30 Days for comment
- Manufacturer LAT Research
 - December 15, 2002 thru February 15, 2003
- CBRN APR Federal Register Notice
 - March 1, 2003
- CBRN APR Certification
 - March 15, 2003







- Manufacturer Research Program: 2 Parts
 - Part 1: Workshop, LAT Test Experience
 - Half Day Discussion of Respirator Testing
 - Part 2: R & D Live Agent Testing
 - 2 Days, 4 Agent Tests
 - Part 1 and Part 2 Independent Events
 - Part 1 Date and Time to be Announced







- Manufacturer R&D Prototype Test Application To NIOSH
 - Respirator Identification
 - Model # & Technical Description
- Program Cost: \$4500/ SMARTMAN Test
- Program Details To Be Posted on Website







CBRN APR Use Scenarios

Warm Use: Less than IDLH concentrations, sustained warm zone support operations; long term use for decon, traffic control, rehabilitation, rescue and recovery; agent known and quantified

Crisis Provision: Contingency use for short duration; above IDLH and high physiological (flow) demand possible; contingency for unforeseen factors such as a secondary device or pockets of entrapped hazard, emergency escape







CBRN APR: Cautions and Limitations

- 14G Gas Mask Cautions and Limitations
- Cautions and Limitations derived from CBRN –SCBA
- Specific Cautions and Limitations for CBRN –APR

*Refer to list of Cautions and Limitations contained in the Concept Paper







CBRN APR: Service Life

- Assign a rating factor to classify filters for use
- Base Ratings on Capacity of Filter
- Agent known and quantified
- Rating established based on Agent IDLH and monitored concentration







- CBRN APR Rating:
 - CBRN APR Use ≤ IDLH
 - Contingency Protection To 3 X IDLH
 - Service Time Testing:
 - Short Duration: 15, 30, 45 minutes
 - Long Duration: 60, 90, 120 minutes
 - Specified By Applicant
 - Single Use
 - CBRN Rating = Capacity @ IDLH







- CBRN Rating = Capacity @ IDLH
- CBRN 15 Means
 - 15 = 15 minute life at IDLH
 - 15 = 30 minutes at 50% IDLH
- CBRN 60 Means
 - 60 minutes @ IDLH
 - 120 minutes @ 50% IDLH







CBRN APR – Quality Assurance

CBRN APR Quality Assurance Provisions

- 42 CFR, Part 84 Subpart E. Quality Control
- Sampling / Test / Inspection Plan
 - Barrier Materials
 - Mechanical Seals Forming A Barrier With Ambient
 - Mechanical Connector Threads
 - Mechanical Connector Sealing Gland
 - Gasket Dimensions, Material, Hardness
 - Final Filter Tests







- Testing will be performed in two locations
 - NPPTL 42 CFR, Service Life and Particulate Testing SBCCOM Live Agent Testing and LRPL
- •Environmental Conditioning will be performed at both locations
- Testing at NPPTL 53 days
- •Total cost estimated at \$88,000





Penetration and Permeation Testing

Chemical Analysis Team, Edgewood, MD

6 APR systems (3-GB; 3:HD)

Environmental Conditioning / Testing

Time - 34 Days (continuous)

Cost - \$7400

Live Agent Testing

3 - GB Testing 3 - HD Testing

Time - 6 Days

Cost - \$27800

Total Cost and Time

Time - 40 days

Cost - \$ 35200







Protection Factor Group, Edgewood, MD 25 – 29 APR systems (Size is tariff dependant)

Laboratory Respirator Protection Level

Time - 5 days Cost - \$10000

Modified Laboratory Respirator Protection Level


Time - 5 days Cost - \$5000

Laboratory Respirator Protection Level; Interchangeability (Modified LRPL)

Total Cost and Time Time – 10 Days Cost – \$ 15,000







42 CFR Testing Total Cost and Time

Time – 53 Days Cost – \$ 22,100







Open Comment Period







Information Docket

Mail: NIOSH Docket Office

Robert A. Taft Laboratories, M/S C 34

4676 Columbia Parkway

Cincinnati, OH 45226

Email: <u>niocindocket@cdc.gov</u>

• Fax: (513) 533-8285

Phone: (513) 533-8303

NPPTL Web Site: http://www.cdc.gov/niosh/npptl



