

Human Factor Requirements

Field of View (FOV)

Fogging

Communications



Mr. Frank Palya, NIOSH



29 April 2003





Field of View (FOV)

- Requirement:
 - Visual Field Score (VFS) ≥ 70
 - 1 Respirator that anatomically best fits the Head Form of the Apertometer of EN 136: 1998 or equivalent; VFS = Average Score of 3 Fittings
 - Derived From: *AMA Guides*; Functional Impact of VFS=70 Translates to Mild Visual Impairment (Requires Scanning For Obstacles)

FOV Test Equipment and Methodology



Example: Escape Hood Respirator 1: Fit 1.



VFS = 96

Field of View Test Results

Escape Respirator	VFS FIT 1	VFS FIT 2	VFS FIT 3	VFS Avg.
Concept 1	96	96	92	94.7
Concept 2	103	104	102	103
Concept 3	93	94	93.3	93
Concept 4	97	98	99	98

Fogging Test Conditions and Equipment

- 2 Environmental Test Conditions:
 - Low Temp Chamber -10.5°C (13°F)
 - Hot Humid Chamber 32.2°C (90°F); RH @ 60%
- 3 Visual Acuity Scores will be Taken
 - 1. Respirator Donned in ambient condition 22.2°C (72°F)
 - 2. Immediately Upon enter into Environmental Chamber
 - 3. During 2 min Rest Period after 5 min of Exercise
- Test Equipment
 - Environmental Chamber
 - Treadmill
 - Snellen Logarithmic Low Acuity Chart 2000 @ 40cm

Fogging Resistance Requirement

- Number of Tests: 2 Tests per Environmental Condition
- 2 Different Human Subjects per Environmental Condition (Same Human Subject Allowed for Cold and Hot/Humid)
- $$\text{Avg. } VAS_{\text{Chamber}} = \frac{VAS_{\text{Chamber (1)}} + VAS_{\text{Chamber (2)}}}{2}$$
- $$PR(\%) = \left(\frac{\text{Avg. } VAS_{\text{Chamber}}}{VAS_{\text{Ambient}}} \right) \times 100$$
- All 4 Performance Ratings (%) $\geq 70 \%$

Sample Fogging Test Results

Cold Chamber Condition = -11.6°C (11°F)
Avg. Ambient = 24.3°C (75.8°F); RH = 46.1%

Model	VAS Ambient	1 st VAS In Chamber	2 nd VAS In Chamber	PR (%)
Model A	95	90	85	92
Model B	95	95	60	82
Model C	105	100	100	95
Model D	90	75	60	75

Sample Fogging Test

Hot/Hum Chamber Condition 30.7 °C (87.4 °F)/ RH = 68.2%
Avg. Ambient = 27.2 °C (81.9 °F)

Model	VAS Ambient	1 st VAS In Chamber	2 nd VAS In Chamber	PR (%)
Model A	100	85	85	85
Model B	105	90	40	62
Model C	105	95	95	90
Model D	100	100	90	95

Communication Requirement

- The Communication (Speech Intelligibility) capability is an Optional Feature
- If Communication Feature NIOSH Qualified:
 - Requirement: $\geq 70\%$

Communication Methodology

- Modified Rhyme Test (MRT)
- Background Noise = 60 dBA \pm 2 dBA consisting of a broadband “pink” noise
- Distance = 10 FT (3.1m)
- 10 MRT Trials, Yielding:
 - 15 MRT Scores per listener with Respirator and 15 w/o respirator ; (3 Listeners, 5 Speakers)

Communication MRT Data

Escape Respirator	Concept X	Concept Y	Concept Z
Background Noise	63	63	64
Avg PR(%)	36	45	36
Std. Dev.	18	11	16
Min PR (%)	24	32	11
Max PR (%)	51	66	78

Summary / Conclusion

- Field of View (FOV)
 - Requirement: VFS \geq **70 Points**
 - Same FOV STP as NIOSH CBRN Full Facepiece Gas Mask
- Fogging
 - Requirement: PR(%) \geq **70 %**
 - Conditions: Don at 22.2 °C (72 °F) and enter Low Temp -10.5 °C (13 °F) and Hot Humid 32.2 °C (90 °F); RH @ 60%
- Communications
 - Requirement: Optional
 - For Communication Qualifier, Requirement \geq **70%**
 - Same Communication STP as NIOSH CBRN Full Facepiece Gas Mask