

This presentation should not be considered a final statement of NIOSH policy or of any agency or individual who was involved. This information is intended for use in advancing knowledge needed to protect workers. Comments regarding this presentation may be submitted to the NIOSH Docket Office.

Test Sequence and Required Quantity For CBRN Self-Contained Escape Respirators

Mr. Frank Palya, NIOSH
25 June 2003



Self-Contained Escape Test Sequence and Quantity

Test Order	Breathing Gas	Human Factors	Penetration and Permeation Testing	LRPL Test
Qty	12	5 - 11	6	30 -65
1.	Breathing Gas	Field of View	Hot Constant Storage	Donning
2		Fogging Resistance	Cold Constant Storage	LRPL
3		Flammability and Heat Resistance	Humidity	
4.			Transport. / Vibration	
5.			Drop	
6.			Live Agent System Testing	
7.			Note: 2 units Tested Before Environ / Trans. / Vib.	

Breathing Gas

Quantity Required	Test	Test Method
12	Breathing Gas Concentration	Human Subject Testing

Human Factors

Quantity: Total 5 - 11	Test	Test Method
1 - 3	Field of View (FOV)	NIOSH: CET-APRS-STP-CBRN-0312
3 - 9	Fogging Resistance	NIOSH: CET-APRS-STP-CBRN-0321
2	Flammability and Heat Resistance	Equipment IAW EN 136:1998

- Note: 1. Same Respirators for FOV and Flame and Fogging Resistance
2. Tests shall be performed as listed, top to bottom

Penetration and Permeation Testing

Quantity: 6 Total	Test	Test Method
2	Permeation and Permeation	Similar to NIOSH SCBA GB and HD Live Agent Test
4	High Temperature Storage	MIL-STD-810F, Method 501.4 71°C (160°F) Constant; 5 Weeks
4	Low Temperature Storage	MIL-STD-810F, Method 502.4. -31 °C/(- 24 °F) Constant; 3 Days
4	Humidity	MIL-STD-810E, Method 507.3 Natural, Cycle 1, Quick Look.
4	Transportation / Vibration	MIL-STD-810F, Method 514.5. U.S Highways; 3 Axes; 12 Hrs/Axis
4	Drop	3 Foot Drop; 1 Drop per Axis
4	Permeation and Permeation	Similar to NIOSH CBRN GB and HD Live Agent Test

Laboratory Respirator Protection Level Test (LRPL)

Quantity Required	Test	Test Method
30-65	Donning	To Be Determined
30-65	LRPL	Similar to -STP-CBRN-0352

- Note:
1. Same Respirators will be used for all tests;
 2. Tests shall be performed as listed, top to bottom



Questions

Mr. Frank Palya, NIOSH

- fc2@cdc.gov
- 412 386-6637

<http://www.cdc.gov/niosh/npptl/default.html>

1-800-35-NIOSH

