

This presentation should not be considered a final statement of NIOSH policy or of any agency or individual who was involved. This information is intended for use in advancing knowledge needed to protect workers. Comments regarding this presentation may be submitted to the NIOSH Docket Office.

CBRN Escape Respirators

Chemical Warfare Agent Testing

Wayne K. Davis

SBCCOM



CWA Testing Conducted at Edgewood Chemical Biological Center (ECBC) in Support of Escape Hood Projects

- **Escape Hoods for Select Federal Agencies – 1985**
- **Technical Support Working Group (TSWG) Escape Hood– 2000-Present**
- **Joint Service Chemical Environment Survivability Mask – 2001- Present**
- **NIOSH Baseline Testing for Escape Hoods - 2003**

CWA System Testing


SMARTMAN System (SiMulant Agent Resistant
Test MANikin)

A headform system used to evaluate Chemical Warfare Agent penetration and permeation effects on respirators under simulated breathing conditions with “perfect” respirator sealing to the SMARTMAN.

SMARTMAN Equipment

- ◆ Syringe pump to generate agent vapors
- ◆ Air Controller
- ◆ Breather Pump, Sinusoidal
- ◆ Mixing Chamber
- ◆ MINICAMS or Gas Chromatograph - Dynatherm
- ◆ HYFED (Hydrogen Flame Emission Detector)
- ◆ Miran Detectors
- ◆ Computer

Equipment Setup




Equipment Setup

Miran

SMARTMAN
Headform

Mixing Chamber



MiniCAMS

TDA99

Test Method Development & Validation

- ◆ Established test procedures
- ◆ Develop test protocol
- ◆ Validate test method/procedures for specific protocol
- ◆ Document as a Standard Test Procedure



**Approved and Validated Test Methods
for SCBA and APR**

Escape Hood Testing Changes



- Neck seal is taped to obtain a “leak tight” SMARTMAN to hood interface. Seal verified with a TDA-99 particle leak tester.
- TDA-99 Test accomplished on agent test SMARTMAN





Escape Hood CWA Baseline Data

- **Commercial Escape Hoods were obtained and tested to determine potential CWA capabilities**
- **SCBA CBRNE Test Parameters Used**
 - **Sarin (GB) Challenge: 2000 mg/m³ for 30 minutes**
 - **Mustard (HD) Challenge: 300 mg/m³ for 30 minutes and liquid HD on the hood system at 10 grams/m²**
 - **Breather flow rate of 40 liters/minute**
- **Considered worse case scenario**



GB Sample Data




Sample GB Data




Sample GB Data





Sample GB Data





**Two Samples Showed
“Baseline” Results**




Sample HD Data




Sample HD Data



Sample HD Data



**Three Samples Showed
“Baseline” Results**



Lessons Learned

- **Other Tests Can Significantly Impact CWA Results**
 - **High temperature Storage**
 - **Packaged Rough handling**
- **Materials and Methods of Construction – Soft Material to Hard Material Interfaces**

Summary of Results

- **Escape Hoods Are Capable of High Level CWA Protection**