



**Quality Control Specimen Certification  
Acylcarnitines Set 1— January 9, 2012**

**Analyses Method: MSMS NON-DERIVATIZED - MS/MS NON-KIT**

Enrichment Levels (endogenous levels not included)

<i>Analyte (μmol/L whole blood)</i>	<i>Lot</i>	<i>Base</i>	<i>Lot</i>	<i>Low</i>	<i>Lot</i>	<i>Intermediate</i>	<i>Lot</i>	<i>High</i>
Free carnitine (C0)	165	0	166	10.0	167	20.0	168	30.0
Acetylcarnitine (C2)	165	0	166	10.0	167	20.0	168	30.0
Propionylcarnitine (C3)	165	0	166	3.0	167	7.5	168	12.0
Butyrylcarnitine (C4)	165	0	166	1.0	167	2.5	168	5.0
Isovalerylcarnitine (C5)	165	0	166	0.5	167	1.5	168	3.0
Hexanoylcarnitine (C6)	165	0	166	0.5	167	1.0	168	2.5
Octanoylcarnitine (C8)	165	0	166	0.5	167	1.0	168	2.5
Decanoylcarnitine (C10)	165	0	166	0.5	167	1.0	168	2.5
Dodecanoylcarnitine (C12)	165	0	166	0.5	167	1.0	168	2.5
Myristoylcarnitine (C14)	165	0	166	0.5	167	1.5	168	3.0
Palmitoylcarnitine (C16)	165	0	166	4.0	167	8.0	168	12.0
Stearoylcarnitine (C18)	165	0	166	1.0	167	2.0	168	5.0
Malonylcarnitine (C3DC)	165	0	166	0.5	167	1.5	168	3.0
Glutarylcarnitine (C5DC)	165	0	166	0.5	167	1.0	168	2.5
3-Hydroxyisovalerylcarnitine (C5OH)	165	0	166	0.5	167	1.5	168	2.5
3-Hydroxypalmitoylcarnitine (C16OH)	165	0	166	0.5	167	1.0	168	2.5



**Newborn Screening  
Quality Assurance Program**  
**Quality Control Specimen Certification**  
**Acylcarnitines Set 1— January 9, 2012**

ANALYTICAL INFORMATION Lot Numbers, Mean Values ( $\bar{x}$ ,  $\mu\text{mol/L}$  whole blood), and 95% Confidence Limits (CL)

Analyte	Lot	Mean/ 95% CL	Lot	Mean/ 95% CL	Lot	Mean/ 95% CL	Lot	Mean/ 95% CL
C0	165	$\bar{x} = 7.7$ CL = 6.7 – 8.6	166	$\bar{x} = 16.5$ CL = 15.1 – 18.0	167	$\bar{x} = 24.5$ CL = 21.2 – 27.7	168	$\bar{x} = 34.1$ CL = 27.9 – 40.3
C2	165	$\bar{x} = 5.8$ CL = 4.7 – 6.9	166	$\bar{x} = 14.1$ CL = 11.6 – 16.6	167	$\bar{x} = 22.2$ CL = 18.7 – 25.6	168	$\bar{x} = 30.7$ CL = 23.6 – 37.8
C3	165	$\bar{x} = 0.73$ CL = 0.5 – 1.0	166	$\bar{x} = 3.5$ CL = 2.5 – 4.5	167	$\bar{x} = 7.3$ CL = 5.0 – 9.6	168	$\bar{x} = 11.5$ CL = 8.2 – 14.8
C4	165	$\bar{x} = 0.1$ CL = 0.0 – 0.1	166	$\bar{x} = 1.1$ CL = 0.8 – 1.3	167	$\bar{x} = 2.4$ CL = 1.8 – 3.1	168	$\bar{x} = 4.9$ CL = 3.6 – 6.2
C5	165	$\bar{x} = 0.1$ CL = 0.0 – 0.1	166	$\bar{x} = 0.5$ CL = 0.4 – 0.6	167	$\bar{x} = 1.3$ CL = 1.0 – 1.5	168	$\bar{x} = 2.6$ CL = 1.9 – 3.2
C6	165	$\bar{x} = 0.0$ CL = 0.0 – 0.0	166	$\bar{x} = 0.4$ CL = 0.3 – 0.5	167	$\bar{x} = 0.7$ CL = 0.5 – 1.0	168	$\bar{x} = 2.0$ CL = 1.5 – 2.5
C8	165	$\bar{x} = 0.0$ CL = 0.0 – 0.0	166	$\bar{x} = 0.4$ CL = 0.3 – 0.6	167	$\bar{x} = 0.9$ CL = 0.7 – 1.2	168	$\bar{x} = 2.4$ CL = 1.8 – 2.9
C10	165	$\bar{x} = 0.0$ CL = 0.0 – 0.1	166	$\bar{x} = 0.5$ CL = 0.4 – 0.6	167	$\bar{x} = 1.1$ CL = 0.8 – 1.3	168	$\bar{x} = 2.7$ CL = 2.0 – 3.3
C12	165	$\bar{x} = 0.0$ CL = 0.0 – 0.0	166	$\bar{x} = 0.4$ CL = 0.3 – 0.5	167	$\bar{x} = 0.8$ CL = 0.6 – 0.9	168	$\bar{x} = 2.0$ CL = 1.6 – 2.3
C14	165	$\bar{x} = 0.0$ CL = 0.0 – 0.0	166	$\bar{x} = 0.4$ CL = 0.3 – 0.5	167	$\bar{x} = 1.2$ CL = 0.9 – 1.6	168	$\bar{x} = 3.2$ CL = 2.8 – 3.6
C16	165	$\bar{x} = 0.4$ CL = 0.3 – 0.6	166	$\bar{x} = 3.1$ CL = 2.3 – 4.0	167	$\bar{x} = 5.6$ CL = 4.8 – 6.4	168	$\bar{x} = 8.7$ CL = 7.2 – 10.3
C18	165	$\bar{x} = 0.5$ CL = 0.3 – 0.8	166	$\bar{x} = 0.8$ CL = 0.4 – 1.2	167	$\bar{x} = 1.4$ CL = 0.8 – 1.8	168	$\bar{x} = 2.6$ CL = 1.5 – 3.8
C3DC + C4OH	165	$\bar{x} = 0.0$ CL = 0.0 – 0.1	166	$\bar{x} = 0.1$ CL = 0.0 – 0.1	167	$\bar{x} = 0.1$ CL = 0.1 – 0.2	168	$\bar{x} = 0.2$ CL = 0.2 – 0.3
C5DC	165	$\bar{x} = 0.0$ CL = 0.0 – 0.1	166	$\bar{x} = 0.4$ CL = 0.2 – 0.5	167	$\bar{x} = 0.7$ CL = 0.4 – 1.0	168	$\bar{x} = 1.6$ CL = 1.1 – 2.0
C5OH	165	$\bar{x} = 0.5$ CL = 0.4 – 0.7	166	$\bar{x} = 1.0$ CL = 0.7 – 1.3	167	$\bar{x} = 1.8$ CL = 1.4 – 2.1	168	$\bar{x} = 2.7$ CL = 1.9 – 3.4
C16OH	165	$\bar{x} = 0.0$ CL = 0.0 – 0.0	166	$\bar{x} = 0.3$ CL = 0.2 – 0.4	167	$\bar{x} = 0.6$ CL = 0.4 – 0.7	168	$\bar{x} = 1.5$ CL = 1.2 – 1.7

**Note:** The values provided in the above tables are for reference use only. The mean value and confidence limits (CL) are determined by CDC for each Quality Control (QC) lot. Each participating laboratory must establish its own mean values and CL for its test method with these QC materials. Temporary estimates of mean values and CL can be determined after 10 successive, independent measurements. *Slazyk WE, Hannon WH. Quality assurance in the newborn screening laboratory. In: Therrell BL Jr, editor. Laboratory methods for neonatal screening. Washington (DC): American Public Health Association, 1993:23-46.*